

NATURAL GROUND SPIKE MOUNTING INSTRUCTIONS

CAUTION: CHECK UNDERGROUND UTILITIES BEFORE INSTALLING

Tools Required:

- Rubber Mallet
- 3/4" Ratchet Wrench
- 3/4" Wrench

Parts Included:

- 1 Natural Ground Spike
- 1 Torsion Spring & Hardware
- Post

THESE INSTRUCTIONS ARE FOR A SEMI-PERMANENT APPLICATION. FOR A PERMANENT APPLICATION, USE A POST HOLE DIGGER TO DIG OUT A HOLE 18" DEEP. FILL THE HOLE WITH QUICK CEMENT. PLACE AND LEVEL SPIKE AND ALLOW FOR APPROPRIATE DRY TIME.



- *Identify desired mounting location*
- *Using a rubber mallet, tap the spike into the ground until the ring is flat against the ground*



- *Using the wrench and ratchet, attach the spring to the stem of the ground spike with the included hardware*



- *Insert the post into the other end, and secure them using the remaining hardware*



- *After assembly, allow 24 hours for the ground to settle for maximum stability*

FLEX
 **POST**[®]

339 1/2 Centre St.
Petrolia, ON N0N 1R0
888-307-6610 • www.Flexpostcanada.ca